

Data Format



Terminal



Disable or Enable Terminal


Code Programming ON




“Terminal” is the termination for a string of barcode messages. It is fixed to the right and the very end of a barcode transmission. The major difference between "Terminal" and "User Suffix" is that the information and the decoded messages in user suffix could be formatted but couldn't in terminal.

Code Programming OFF



2   
 Disable Terminal  
 【Pro CMD: 99904110】


  
 Enable Terminal  
 【Pro CMD: 99904111】


43-


44

Program Terminal

Read “Program Terminal” . Then program terminal byte(s). At last, read “Save programming” . The terminal byte is programmed in its hex values. See example below.

  
 Program Terminal  
 【Pro CMD: 99904112】

3   
 Set Terminal as 0x0D and Enable Sending  
 【Pro CMD: 99904113】

  
 Set Terminal as 0x0D,0x0A and Enable Sending  
 【Pro CMD: 99904114】

**E**  
*example*

-----  
 Program a Windows OS general line feed and carriage return as terminal

1. Read “Code Programming ON”
  2. Read “Program Terminal”
  3. Read “Set Terminal as 0x0D,0x0A and Enable Sending”
  4. Read “Save ”
  5. Read “Code Programming OFF”
  6. Read “Allow Terminal” to enable above programming. A line feed will appear to the right of a barcode.
-